



## Technical data

**Portable hand-operated 3-phase starter for D-O-L start of pumps with thermal contacts built-in.**

<b>Type:</b>	START 351
<b>Voltage:</b>	3 x 380 - 415 V
<b>Frequency:</b>	50-60 Hz
<b>Current range:</b>	1,0 - 32 A
<b>Overload protection:</b>	Thermal/magnetic overload protection
<b>Monitoring:</b>	Monitoring of thermal contacts with manual reset Phase sequence indicator
<b>Connection supply:</b>	CEE-plug 5-pole 16 or 32 A, with phase inverter CEE-plug 4-pole 16 or 32 A
<b>Connection pump:</b>	Terminal connection with cable glands
<b>General:</b>	Degree of protection IP54 Size 285 x 110 x 95 mm Weight 0,8 kg CE-marked

Type	Voltage (V)	Current range (A)	Type of supply connection	Pump cable Ø (mm)	Part no.
START 351-400-B-516-	1,6	1,0 - 1,6	CEE plug	11 – 21	554 30 00
	2,5	1,6 - 2,5	5-pole 16 A	-"-	554 30 01
	4	2,5 - 4,0	3P + E + N	-"-	554 30 02
	6	4 - 6,3		-"-	554 30 03
	10	6 - 10		-"-	554 30 04
	14	9 - 14		-"-	554 30 05
	18	13 - 18			554 30 06
START 351-400-B-532-	1,6	1,0 - 1,6	CEE plug	11 – 21	554 30 10
	2,5	1,6 - 2,5	5-pole 32 A	-"-	554 30 11
	4	2,5 - 4,0	3P + E + N	-"-	554 30 12
	6	4 - 6,3		-"-	554 30 13
	10	6 - 10		-"-	554 30 14
	14	9 - 14		-"-	554 30 15
	18	13 - 18		-"-	554 30 16
	23	17 - 23		-"-	554 30 17
	25	20 - 25		-"-	554 30 18
	32	24 - 32		18 – 25	554 30 19
START 351-400-B-416-	1,6	1,0 - 1,6	CEE plug	11 – 21	554 30 20
	2,5	1,6 - 2,5	4-pole 16 A	-"-	554 30 21
	4	2,5 - 4,0	3P + E	-"-	554 30 22
	6	4 - 6,3		-"-	554 30 23
	10	6 - 10		-"-	554 30 24
	14	9 - 14		-"-	554 30 25
	18	13 - 18			554 30 26
START 351-400-B-432-	1,6	1,0 - 1,6	CEE plug	11 – 21	554 30 30
	2,5	1,6 - 2,5	4-pole 32 A	-"-	554 30 31
	4	2,5 - 4,0	3P + E	-"-	554 30 32
	6	4 - 6,3		-"-	554 30 33
	10	6 - 10		-"-	554 30 34
	14	9 - 14		-"-	554 30 35
	18	13 - 18		-"-	554 30 36
	23	17 - 23		-"-	554 30 37
	25	20 - 25		-"-	554 30 38
	32	24 - 32		18 - 25	554 30 39